


6001 RL 🗙 Y Z 8 💥






Warranty disclaimer: If the devices are not installed in accordance with the correct installation instructions, all warranty will void.


The information and Specifications in this document are subject to change without notice. da'LUX assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual. Please read all instructions prior to assembly, mounting and operating the device. The installation of device must be performed by a recognized electrician and according to the national regulations on electric installations. Leave a copy of this document with person responsible for the maintenance. This document is part of the general selling conditions of da'LUX.




T +32 51 490 900 info@da-lux.be www.da-lux.be

100







The opening for the luminaire must be above a drainage layer of 25cm (e.g. gravel). Layer suits if it's dry, 20 minutes after you filled it with water.



Do not install the luminaire into a hollow areas and mount the floorkit flush to the surface.



Electrical connection at least IP68. Use outdoor certified cable only in accordance with the local regulations.



T +32 51 490 900

info@da-lux.be

www.da-lux.be

da'lux